



FlexiPoint Pointing Procedure

Over Point

- Use FlexiPoint straight from bucket
- Remove all loose pointing from ridge
- Brush ridge with wire brush taking care to remove all moss and fungi in area to be pointed
- Spray pointing area with PVA and allow to dry
- Point all holes and voids with traditional sand and cement mortar
- Over point entire ridge with FlexiPoint using a steel trowel at 3-5mm thickness
- Take care to smooth with the trowel as you go
- Do not apply FlexiPoint in temperatures of 5 degrees C or less

New Point

- Use FlexiPoint straight from bucket
- Bedding cement should be struck off at 90 degree angle and free of large holes & voids while ensuring no bedding cement residue is left on the edge of the ridge cap interface.
- Spray pointing area with PVA and allow to dry
- FlexiPoint should be applied with steel trowel at a thickness of 3-5mm
- Take care to smooth as you go
- Do not apply FlexiPoint in temperatures of 5 degrees C or less